


ASSEMBLY INSTRUCTIONS


DINING CHAIR MODEL#:SDC5068









1




2



3



4



5

